



- Subject : Installation of a flash light
- Effectivity type: DG-800, DG single seaters  
variants: All variants with a single piece canopy
- Accomplishment : optional
- Reason : To increase the visibility of the aircraft and hence reduce the danger of mid-air collisions, a circular flash light may be installed in the fuselage nose.
- Instructions :
  1. The „Operating manual flash light for DG-single seater“ must be carried on board. It should be filed in the folder of the flight manual.
  2. Installation of a flash light according to “installation instructions TM DG-G-14”, section 3B.
  3. Install the following placard directly below the placard Cockpit Check:  

FLASH LIGHT off?
  4. Installation of an additional Battery Z73/0 or Z73/2 in the baggage compartment.
- Material : Operating manual FLASH LIGHT for DG single seaters.  
Installation instructions TM DG-G-14, and the material listed therein  
Marking, see instruction 3  
and the material listed therein
- Weight and balance : Influence of flash light negligible. If a new battery was installed, the new weight and balance have to be determined by weighing.
- Remarks : 
 

All Instructions:

  1. EASA countries: The actions have to be performed according to the regulations of the Part M in an approved maintenance organisation and released according to M.A.801.
  2. Non EASA countries: The actions have to be performed in a licensed workshop. All instructions are to be inspected and entered in the aircraft logs by a licensed inspector.

If you have any questions concerning this TN please contact DG  
Flugzeugbau: Tel.: 0049 7251 3020-0, e-mail: dg@dg-flugzeugbau.de

Bruchsal, date:  
Oct. 11,2017

Author: J.B. Wassenaar Modifications/repairs approved under the authority of DOA Ref.  
EASA.21J.530 under Minor Change No. TM DG-G-14, dated Oct. 24, 2017.